

Датчики давления S040

Технические характеристики

По вопросам продаж и поддержки обращайтесь:

Алматы (727)345-47-04
Ангарск (3955)60-70-56
Архангельск (8182)63-90-72
Астрахань (8512)99-46-04
Барнаул (3852)73-04-60
Белгород (4722)40-23-64
Благовещенск (4162)22-76-07
Брянск (4832)59-03-52
Владивосток (423)249-28-31
Владикавказ (8672)28-90-48
Владимир (4922)49-43-18
Волгоград (844)278-03-48
Вологда (8172)26-41-59
Воронеж (473)204-51-73
Екатеринбург (343)384-55-89

Иваново (4932)77-34-06
Ижевск (3412)26-03-58
Иркутск (395)279-98-46
Казань (843)206-01-48
Калининград (4012)72-03-81
Калуга (4842)92-23-67
Кемерово (3842)65-04-62
Киров (8332)68-02-04
Коломна (4966)23-41-49
Кострома (4942)77-07-48
Краснодар (861)203-40-90
Красноярск (391)204-63-61
Курск (4712)77-13-04
Курган (3522)50-90-47
Липецк (4742)52-20-81

Магнитогорск (3519)55-03-13
Москва (495)268-04-70
Мурманск (8152)59-64-93
Набережные Челны (8552)20-53-41
Нижний Новгород (831)429-08-12
Новокузнецк (3843)20-46-81
Ноябрьск (3496)41-32-12
Новосибирск (383)227-86-73
Омск (3812)21-46-40
Орел (4862)44-53-42
Оренбург (3532)37-68-04
Пенза (8412)22-31-16
Петрозаводск (8142)55-98-37
Псков (8112)59-10-37
Пермь (342)205-81-47

Ростов-на-Дону (863)308-18-15
Рязань (4912)46-61-64
Самара (846)206-03-16
Санкт-Петербург (812)309-46-40
Саратов (845)249-38-78
Севастополь (8692)22-31-93
Саранск (8342)22-96-24
Симферополь (3652)67-13-56
Смоленск (4812)29-41-54
Сочи (862)225-72-31
Ставрополь (8652)20-65-13
Сургут (3462)77-98-35
Сыктывкар (8212)25-95-17
Тамбов (4752)50-40-97
Тверь (4822)63-31-35

Тольятти (8482)63-91-07
Томск (3822)98-41-53
Тула (4872)33-79-87
Тюмень (3452)66-21-18
Ульяновск (8422)24-23-59
Улан-Удэ (3012)59-97-51
Уфа (347)229-48-12
Хабаровск (4212)92-98-04
Чебоксары (8352)28-53-07
Челябинск (351)202-03-61
Череповец (8202)49-02-64
Чита (3022)38-34-83
Якутск (4112)23-90-97
Ярославль (4852)69-52-93

Россия +7(495)268-04-70

Казахстан +(727)345-47-04

Беларусь +(375)257-127-884

Узбекистан +998(71)205-18-59

Киргизия +996(312)96-26-47

эл.почта: sow@nt-rt.ru || сайт: <https://suto.nt-rt.ru/>

S040

Atmospheric Sensor

The SUTO S040 Atmospheric Sensor is a reliable and accurate instrument for simultaneous measurement of temperature, humidity and air pressure. With its multi-parameter capabilities and flexible options, it is designed to meet the diverse needs of various industrial applications.




ALL IN ONE

Temperature,
humidity,
atmospheric pressure



**EASY
INSTALLATION**

Incl. wall
mounting clip



**MODBUS/RTU
INTERFACE**

Digital data
readout



**COMPACT
DESIGN**

Installation in
tight space



Benefits

- ✓ Measure Temperature, humidity and atmospheric pressure, altitude simultaneously.
- ✓ Optional displays units are available
- ✓ Intelligent filtering algorithm ensures accuracy and stability
- ✓ Modbus/RTU digital data output
- ✓ High protection class IP66 for harsh environmental conditions
- ✓ Simple installation and efficient handling

Application

- Compressor efficiency: FAD calculation for compressor tests
- HVAC & Industrial: Optimise air quality and conditions in manufacturing and warehousing.
- Labs & Automation: Supports controlled environments and intelligent building integration.

Technical Data

Measurement

Temperature

Measuring range	-40 °C ... 80 °C
Accuracy	±0.3 °C
Resolution	0.1 °C
Response time (T ₅₀)	1 ... 5 s

Humidity

Measuring range	0 ... 100 % RH
Accuracy	±2 % RH @ 25 °C
Resolution	0.1 % RH
Response time (T ₅₀)	1 ... 5 s

Atmospheric pressure

Measuring range	0.3 ... 120 kPa
Accuracy	±10 Pa
Resolution	1 Pa
Response time (T ₅₀)	1 ... 5 s

Signal / Interface & Supply

Power supply	5 ... 24VDC
Communication protocol	Modbus/RTU
Hardware interface	RS-485


Operating conditions

Ambient temperature	-40 °C ... 80 °C
Ambient humidity	0 ... 100 % RH
Medium	Air, N ₂ , CO ₂
Operating Pressure	Atmospheric pressure (0.3 ... 120 kPa)

General data


Electrical connection	M12 connector, 4 pole
Housing material	SS304
Protection class	IP66/67
Weight	75 g
Approvals	CE
Transport Temperature	-55 °C ... 80 °C
Storage temperature	-55 °C ... 80 °C

S040 Dimensions



Installation

L-shaped mounting bracket



Material: SS304
Thickness: 1mm

Ordering

Please use the following table to assist in placing your order with our sales staff.

S040 Atmospheric Sensor

Order No.	Description
-----------	-------------

S654 0400	S040 Atmospheric sensor, measures temperature, humidity and atmospheric pressure, Modbus/RTU (RS-485), Supply: 5 ... 24 VDC, incl. M12 cable with open ends, 5m
-----------	---

Optional display units: S330, S331, S335

Please contact SUTO iTEC for further information on how to connect the S040 Atmospheric Sensor to a display unit via Modbus/RTU.



По вопросам продаж и поддержки обращайтесь:

Алматы (727)345-47-04	Иваново (4932)77-34-06	Магнитогорск (3519)55-03-13	Ростов-на-Дону (863)308-18-15	Тольятти (8482)63-91-07
Ангарск (3955)60-70-56	Ижевск (3412)26-03-58	Москва (495)268-04-70	Рязань (4912)46-61-64	Томск (3822)98-41-53
Архангельск (8182)63-90-72	Иркутск (395)279-98-46	Мурманск (8152)59-64-93	Самара (846)206-03-16	Тула (4872)33-79-87
Астрахань (8512)99-46-04	Казань (843)206-01-48	Набережные Челны (8552)20-53-41	Санкт-Петербург (812)309-46-40	Тюмень (3452)66-21-18
Барнаул (3852)73-04-60	Калининград (4012)72-03-81	Нижний Новгород (831)429-08-12	Саратов (845)249-38-78	Ульяновск (8422)24-23-59
Белгород (4722)40-23-64	Калуга (4842)92-23-67	Новокузнецк (3843)20-46-81	Севастополь (8692)22-31-93	Улан-Удэ (3012)59-97-51
Благовещенск (4162)22-76-07	Кемерово (3842)65-04-62	Ноябрьск (3496)41-32-12	Саранск (8342)22-96-24	Уфа (347)229-48-12
Брянск (4832)59-03-52	Киров (8332)68-02-04	Новосибирск (383)227-86-73	Симферополь (3652)67-13-56	Хабаровск (4212)92-98-04
Владивосток (423)249-28-31	Коломна (4966)23-41-49	Омск (3812)21-46-40	Смоленск (4812)29-41-54	Чебоксары (8352)28-53-07
Владикавказ (8672)28-90-48	Кострома (4942)77-07-48	Орел (4862)44-53-42	Сочи (862)225-72-31	Челябинск (351)202-03-61
Владимир (4922)49-43-18	Краснодар (861)203-40-90	Оренбург (3532)37-68-04	Ставрополь (8652)20-65-13	Череповец (8202)49-02-64
Волгоград (844)278-03-48	Красноярск (391)204-63-61	Пенза (8412)22-31-16	Сургут (3462)77-98-35	Чита (3022)38-34-83
Вологда (8172)26-41-59	Курск (4712)77-13-04	Петрозаводск (8142)55-98-37	Сыктывкар (8212)25-95-17	Якутск (4112)23-90-97
Воронеж (473)204-51-73	Курган (3522)50-90-47	Псков (8112)59-10-37	Тамбов (4752)50-40-97	Ярославль (4852)69-52-93
Екатеринбург (343)384-55-89	Липецк (4742)52-20-81	Пермь (342)205-81-47	Тверь (4822)63-31-35	
Россия +7(495)268-04-70	Казахстан +(727)345-47-04	Беларусь +(375)257-127-884	Узбекистан +998(71)205-18-59	Киргизия +996(312)96-26-47